

Welcome to our decorating guide, in this part of the guide we will take you through the process of cross lining a wall.

To complete this task you will need the following items:

- | | |
|---|--|
| <ul style="list-style-type: none">• Lining Paper• Suitable Wallpaper Paste• Wallpaper Pasting Brush• 2 Trestle tables (or step ladders) and two scaffold boards (there should be a local company where these items can be rented)• Suitable filler (if required) along with a suitable applicator | <ul style="list-style-type: none">• Tape Measure• Spirit Level• Blunt Pencil• Paperhanging brush• Suitable Scissors• Decorating table (pasting table) |
|---|--|

When working at heights always ensure that the structure is safe and secure. Never stretch out, always get down and re-position the scaffold.



Lining Paper.

The benefits of hanging lining paper far outweigh the work involved, especially if you are going to hang expensive or embossed wallcoverings. Lining paper hides any imperfections on the wall and gives an ideal surface onto which to hang your wallcovering.

NOTE: If you intend to hang the lining paper vertically (for painting) then see our guide to [hanging wallpaper](#).

The lining paper should be hung horizontally (across the wall) if you are going to hang a top covering as this stops the edges of the lining paper and the wallcovering falling in the same place and protruding, it also reduces the risk of the final covering upsteating the first.

Roll Calculation


The first thing is to establish how many rolls of lining paper are required, to do this you use a simple calculation.

1. Divide the drop by the width of the lining paper roll.
2. Multiply this figure by the perimeter of the room.
3. Divide by the length of the roll.

For example say the drop (room height) is 2m and the roll width is 0.60m wide that gives: **$2\text{m} \div 0.60\text{m} = 3.4$ (rounded up)**

and let's say the room is 14m in perimeter (including doors/windows) that means the next part of our calculation is: **$3.4 * 14\text{m} = 48$ (rounded up)**

and finally let's say our roll of paper is 11m long, that gives us: **$48 \div 11 = 4.37$ (rounded up)** so we need **5 rolls** of lining paper.



Measure the perimeter (B).
Roll Length (C)
A x B divided by C give rolls required

Fig 1.1

Preparing the Walls

Firstly make sure your trestles and boards are set at the right height and are safe and secure.


If the walls have an old covering then remove it (see our guide to [stripping wallpaper](#)) making sure to get rid of every trace of wallpaper.

Inspect the wall surfaces for cracks, holes and any loose plaster.

For small cracks use a suitable fine filler, for larger cracks and holes use a stronger more suitable filler (see manufacturer's instructions).

To check for any loose plaster, tap the wall around any suspect areas, remove any loose plaster and repair with a suitable plaster repair product (filler if the damaged area is not too big).

When filling try and leave a nice smooth finish, it is better to leave the filled area slightly proud of the surrounding area and then sand down with a fine sandpaper until flush.




Prepare the lengths

First read the manufacturer's instructions on the paste packet, usually paste takes about 20 minutes until it is ready to use, if this is the case then mix the paste now and it will be ready when you need it.


Take your tape measure and pencil, measure down from the ceiling the width of the roll, mark it with your pencil and then take your spirit level and mark a guide line across the wall level with your first mark (see **Fig 1.3**).

Now measure the length of the wall and add 10cm, take the roll of lining paper and cut as many lengths as you need (remember it is the length of the wall plus 10cm) for the one wall.



Pasting the lining paper

Place one of the lengths of paper face down on the pasting table, ensure you have allowed enough time for the paste to thicken, take your pasting brush and apply the paste to the first length, starting at one end, work the paste evenly over the paper working from the middle to the edges (see **Fig 1.4**), fold the paper into a loose concertina as you work, this will make the paper easier to work with. Allow the paper to soak for as long as instructed (see label).



Hanging the lining paper

Now take the paper holding the end in one hand and the concertina section in the other. Put the paper into place butting the end into the corner and lining up the bottom edge with your guide line (see **Fig 1.5**), then work the paper with your paper-hanging brush ensuring not to leave any air bubbles under the paper.

Unfold the paper as you go along the wall removing any air trapped with your paper-hanging brush. When you reach the end push the paper into the corner (there should be 10cm to trim) and then run a blunt pencil or the back of the scissors down the fold as a guide (see **Fig 1.6**), pull the paper away from the wall and then trim the paper using the fold as a guide, then smooth the paper back onto the wall.

Now take the next length and paste as before (if the paper needs a long time to soak you may wish to paste more than one at a time), butt it up against the first length and work your way along the wall as before ensuring to remove all trapped air.


When you hang the last length the chances are it will need trimming along the bottom of the wall. To trim push the paper into the edge and mark along the paper with your blunt pencil, pull the paper away from the wall just enough for you to be able to trim along the line with your scissors.

Now move onto the next wall and repeat the process, once you have lined the whole room, allow the paper 24 hours to dry out before hanging the top covering.



(c) 2002 helpwithdiy.com

Fig 1.5



(c) 2002 helpwithdiy.com

Fig 1.6